

ZUORDNUNG VON LAST-INDEX UND REIFENTRAGFÄHIGKEIT



LI Last-Index	Tragfähigkeit in kg	LI Last-Index	Tragfähigkeit in kg	LI Last-Index	Tragfähigkeit in kg	LI Last-Index	Tragfähigkeit in kg
30	106	50	190	70	335	90	600
31	109	51	195	71	345	91	615
32	112	52	200	72	355	92	630
33	115	53	206	73	365	93	650
34	118	54	212	74	375	94	670
35	121	55	218	75	387	95	690
36	125	56	224	76	400	96	710
37	128	57	230	77	412	97	730
38	132	58	236	78	425	98	750
39	136	59	243	79	437	99	775
40	140	60	250	80	450	100	800
41	145	61	257	81	462	101	825
42	150	62	265	82	475	102	850
43	155	63	272	83	487	103	875
44	160	64	280	84	500	104	900
45	165	65	290	85	515	105	925
46	170	66	300	86	530	106	950
47	175	67	307	87	545	107	975
48	180	68	315	88	560	108	1000
49	185	69	325	89	580	109	1030